

24th May 2006

**To: All Members**

**cc: The Quality and Technical Committee (Code No. 693)  
The Maintenance Committee**

Dear Member,

**SAFETY BULLETIN FROM SCHINDLER  
RE: TYPE W200 AND W250 GEARED MACHINES**


Please find attached Safety Bulletin from Schindler UK in connection with their W200 and W250 geared machines.

We trust that you will find this Bulletin self-explanatory and be guided accordingly.

Yours faithfully




Robert N Lee  
Director, Technical Services



**Schindler**

**Schindler Ltd**  
United Kingdom



Benwell House, Green Street, Sunbury-on-Thames  
Middlesex TW16 6QT

**For the Attention of Mr. David M Fazakerley**  
Lift & Escalator Industry Association  
33-34 Devonshire Street  
London  
W1N 1RF

**Registered**

Reference No. QG3/KD/SR/APP  
Date 15<sup>th</sup> May 2006  
Subject Schindler Gears W200 & W250

Dear Mr. Fazakerley,

We advised LEIA in July 2001 of a potential issue with the W200 and W250 Schindler machines in that cracks might appear at the root of the worm thread. Further investigations have now identified that gear sets exposed to extraordinary shocks may, after prolonged operation, show symptoms of fatigue in the bronze of the crown wheel.

Please see the attached document that outlines our recommendation for examining and monitoring these machine types during maintenance.

Schindler kindly asks you to pass on this information to all your members along with the enclosed picture of a W250 gear.

Thank you for your co-operation and continued support.

Yours sincerely,

**Keith Duberley**  
**Managing Director**


**Steve Reynolds**  
**Technical Manager**

Enclosures:

- Picture of W250 (W200 looks similar)
- Schindler Geared Machines W200, W250 Maintenance, INVENTIO AG, K 601887E-Rev. 8 (LEIA only - NOT for distribution)

Registered in England 662746  
Registered office:  
Benwell House  
Green Street  
Sunbury-on-Thames  
Middlesex TW16 6QT

Tel. +44 (0)20 8818 7900  
Fax +44 (0)1932 758 258  
info@gb.schindler.com  
www.schindlerlifts.co.uk



### Schindler Type W200 and W250 Geared Machines

As previously communicated, cracks may appear at the root of the worm thread in the above gear types, normally leading to abnormal noise and vibration of the machine and jerks during operation.

Furthermore due to periodic nominal speed safety gear and buffer tests, where they have occurred, or unintentional safety gear operations, the gear set is exposed to extraordinary shocks. After prolonged operation, symptoms of fatigue may become apparent in the bronze of the crown wheel (cracks which may or may not be visible to the naked eye).

In isolated cases the bronze material of the crown wheel rim may not withstand the applied load and cause a rupture of the bronze rim, which could lead to an uncontrolled movement of the car and may result in serious injury.

As a preventive measure Schindler is performing **ultrasonic tests** on the bronze rim of the gears concerned, which since installation, have been in operation for more than 10 years.

In order to reduce this risk Schindler, as original equipment manufacturer, strongly recommends performing ultrasonic tests on the crown wheel bronze rim of such installations. Upon request, Schindler will perform this measurement for a fee of £100 per gear. However, if your decision is not to involve Schindler we must point out that the responsibility will then lay with you to identify any possible fatigue of the bronze rim and ensure the ongoing safety of your system.

If the ultrasonic test shows symptoms of fatigue in the bronze material, the gear set has to be exchanged or the installation has to be equipped with a safety device that prevents uncontrolled movement, e.g. a rope brake.

According to experience so far, it can be assumed that the **majority of installations do not show symptoms of fatigue**. However, individual occurrences of fatigue must nonetheless be prevented by the ultrasonic testing identified above. Furthermore, with continuing use and periodic safety gear and buffer operations, may lead to future deterioration of the gear. We strongly recommend that we are commissioned to undertake the ultrasonic test.

Schindler requests that any maintenance company having lifts with such W200 / W250 geared machines in its portfolio, contacts Schindler. In order to receive further information about our offer and the latest Maintenance Instruction, LEIA members are kindly requested to contact our technical hotline on 01932 758 230. In addition, they should inform us of the serial numbers of the gears concerned, so that we are able to check our own records regarding the particular installation.

Manufacturer: - EBI  
- SDS  
- Schindler

If available: Month and Year


Type of gear: - W200  
- W250

|          |            |           |
|----------|------------|-----------|
| SDS      | W250       | Schindler |
| Oil      | Oil        | Hub       |
| MENL 20L | 1-11.5/11M | K 601 420 |
| IM       |            |           |


Com. No. or  
Prod. No

Gear Ratio

Serial No.



# Maintenance



110\_000003\_01

Schindler Geared Machines W200, W250

## Summary

This instruction describes the required preventive and corrective maintenance procedures of the Schindler geared machines W200 and W250.

|   |          |          |          |                |       |             |     |                 |            |            |          |
|---|----------|----------|----------|----------------|-------|-------------|-----|-----------------|------------|------------|----------|
| Modification                                      | 06       | 07       | 08       |                |       |             |     |                 | Prepared   | 19.05.2005 | zurbrure |
| KA No.  | 76210    | 160054   | 160287   |                |       |             |     |                 | Reviewed   | 18.05.2005 | vertesjo |
| KA Date   | 14.06.02 | 17.10.03 | 20.05.05 |                |       |             |     |                 | Norms Chkd | 18.05.2005 | plattle  |
| <b>W200, W250 Geared Machines<br/>Maintenance</b> |          |          |          |                |       |             |     |                 | Released   | 19.05.2005 | riosr2   |
|   |          |          |          |                |       |             |     |                 |            |            | Format   |
| <b>INVENTIO AG</b> CH-6052 Hergiswil              |          |          |          | Classification | 11110 | Lead Office | ES2 | <b>K 601887</b> | <b>E</b>   |            |          |

This Manual is the property of INVENTIO AG and shall only be used by SCHINDLER personnel or authorized SCHINDLER agents for purposes which are in the interest of SCHINDLER. This design and information is our intellectual property. Without written consent, it must neither be copied in any manner, nor used for manufacturing, nor communicated to third parties. Application for such consent should be addressed to: INVENTIO AG, Postfach, CH-6052 Hergiswil NW

## Table of Contents

|          |   |           |
|----------|---|-----------|
| <b>1</b> | <b>Safety Advice</b>                              | <b>3</b>  |
| 1.1      | General   | 3         |
| 1.2      | Symbols Used                                      | 3         |
| <b>2</b> | <b>General Information</b>                        | <b>4</b>  |
| <b>3</b> | <b>*Preventive Maintenance</b>                    | <b>5</b>  |
| 3.1      | *Checking Noise and Vibrations                    | 6         |
| 3.2      | Checking General Machine Conditions               | 6         |
| 3.3      | Checking the Thrust Bearing Play                  | 7         |
| 3.4      | *Checking the Crown Wheel Teeth for Wear          | 8         |
| 3.5      | Checking the Crown Wheel for Damage               | 10        |
| 3.6      | Checking the Worm Shaft for Broken Segments       | 11        |
| 3.6.1    | Check With the "Tooth Feeler"                     | 11        |
| 3.6.2    | Check by Opening the Gearbox                      | 12        |
| 3.7      | Exchanging Oil                                    | 12        |
| 3.8      | Grease outer Bearing                              | 13        |
| 3.9      | Observation and Measures                          | 13        |
| 3.9.1    | Excessive Noise and Vibrations                    | 13        |
| 3.9.2    | Pitting   | 14        |
| 3.9.3    | Jerks   | 14        |
| 3.9.4    | Blocked Gear                                      | 14        |
| 3.9.5    | Development of Gear Set Degradation               | 14        |
| <b>4</b> | <b>*Corrective Maintenance</b>                    | <b>16</b> |
| 4.1      | Exchanging the Hoisting Motor                     | 16        |
| 4.1.1    | Removing the Hoisting Motor                       | 16        |
| 4.1.2    | Installing the Hoisting Motor                     | 16        |
| 4.1.3    | Motor / Worm Shaft Alignment                      | 17        |
| 4.2      | Replacing the Thrust Bearing                      | 18        |
| 4.2.1    | Removing the Thrust Bearing                       | 19        |
| 4.2.2    | Installing the Thrust Bearing                     | 21        |
| 4.3      | Re-Tightening the Thrust Bearing                  | 21        |
| 4.4      | Replacing the Radial Lip Seal                     | 22        |
| 4.4.1    | Removing the Radial Lip Seal On Coupling Side     | 22        |
| 4.4.2    | Removing the Radial Lip Seal On Tacho / IG Side   | 23        |
| 4.4.3    | Installing the Radial Lip Seal On Coupling Side   | 24        |
| 4.4.4    | Installing the Radial Lip Seal On Tacho / IG Side | 24        |
| 4.5      | Repair Oil Leakage                                | 24        |
| 4.6      | Exchanging the Bearing Bushings on Main Shaft     | 25        |
| 4.7      | *Replacement of Gear Set                          | 27        |
| 4.8      | *Setting and Repairing of Mechanical Brake        | 27        |
| <b>5</b> | <b>*Installing the Traction Sheave Damper</b>     | <b>28</b> |
| 5.1      | Delivery Content                                  | 28        |
| 5.2      | Special Tools                                     | 29        |
| 5.3      | Preparatory Work                                  | 30        |
| 5.4      | Installation of the Traction Sheave Damper        | 30        |
| 5.5      | Final Work  | 31        |
| 5.6      | Reporting   | 32        |

# 1 Safety Advice






## 1.1 General

### Safety Requirements

All persons involved must know and follow all company and local safety regulations, with special attention to the following:

- Make sure that there is enough light to work safely.
- Immediately replace damaged or lost safety equipment.
- Keep all tools in good condition.
- Follow instructions when using tools.

In addition to protective clothing, the following safety equipment must be used:

| Description              | Safety Equipment   |
|--------------------------|--|
| Safety Shoes             |   |
| Hardhat                  |    |
| Safety Goggles           |    |
| Full Body Safety Harness |  |
| Protective Gloves        |  |

## 1.2 Symbols Used



### Danger

This symbol indicates a high risk of serious injury. Follow instructions to prevent serious injury or even death.



### Caution

This symbol indicates a risk of personal injury or property damage. Follow instructions to prevent injury or property damage.



### Note

This symbol indicates special or additional information.

## 2 General Information


- The gearbox needs to be regularly checked and maintained according to this instruction.
- The installation must be equipped with a travel time control.
- If the motor is not equipped with a thermal circuit breaker it is recommended to install such a device.
- In case of difficulties, contact your local Schindler representative.



### Caution

Periodic safety gear- and buffer tests with VKN >1 m/s may cause severe overload to the gearbox and therefore should be minimized.

Tests that go beyond the standards (i.e. >VKN and empty car down) should be avoided.




#### General Information

- 1 Oil measuring dipstick
- 2 Plastic cap with oil type plate
- 3 Gear data plate
- 4 Brake drum
- 5 Fly wheel or covered shaft end for hand wheel



### 3 \*Preventive Maintenance

#### Special Tools

| Tool                          | Picture   | Description  |
|-------------------------------|---|--|
| Tooth feeler                  |  | Feeler to inspect the worm shaft teeth<br>Mat.No. 49980131   |
| Inspection mirror             | No picture available  | Mirror to inspect the crown wheel<br>Mat.No. 49980282  |
| Vibration meter (recommended) | No picture available  | <ul style="list-style-type: none"> <li>• MK 4/5</li> <li>• EVA-625</li> <li>• MERLIN (SKF)</li> <li>• Vibration Pen (SKF)</li> </ul> |

#### Maintenance Schedule All W200 & W250

| Task  | Section               | Interval | Special Interval (until one-time Bronze-test done!*) |
|---|-----------------------|----------|--|
| Check noise and vibration                               | 3.1                   | 3 months |  |
| Check general condition of machine                      | 3.2                   | 1 year   |  |
| Check trust bearing play                                | 3.3                   | 1 year   |  |
| Check crown wheel teeth for wear                        | 3.4                   | 1 year   |  |
| Exchange oil in low duty service (<300'000 trips/year)  | 3.7                   | 10 years |  |
| Exchange oil in high duty service (>300'000 trips/year) | 3.7                   | 5 years  |  |
| Grease outer bearing                                    | 3.8                   | 5 years  |  |
| Check mechanical brake                                  | according to K 601888 |          |  |

\*) Refer to local information, Field Information etc.

Maintenance Schedule

#### Maintenance Schedule All EBI, all SDS until June 2003 and all CSE until November 2003

| Task                          | Section | Interval | Special Interval (until one-time Bronze-test done!**)  |
|-------------------------------|---------|----------|--|
| Check crown wheel* for damage | 3.5     | 1 year   | If in country with repeated safety and buffer test and VKN≥1.6m/s, KZU 1:1 or VKN≥2m/s all KZU<br>6 months |

\*) With narrow crown W200: 50-60 mm, W250: 60-65 mm, not later ones with broad rim)  
\*\*) Refer to local information, Field Information etc.

Maintenance Schedule

|  |  |          |    |
|--|--|----------|----|
| W200, W250 Geared Machines Maintenance |  | K 601887 | 08 |
|--|--|----------|----|

Maintenance  
Schedule  
All EBI until  
November 1992  
(Serial No  
<11'226)

| Task   | Section | Interval | Special Interval<br>(until one-time Bronze-test<br>done!**)                              |
|--|---------|----------|--|
| Check worm shaft* for broken<br>tooth  | 3.6     | no       | If VKN $\geq$ 1.6m/s, KZU 1:1 or<br>VKN $\geq$ 2m/s all KZU (all<br>countries)<br>1 year |
| *) not later ones with reinforced worm<br>**) Refer to local information, Field Information etc. |         |          |  |

Maintenance Schedule



### Caution

Make sure no person can enter the car and the landing and car doors are always closed during maintenance work. There is serious danger of injury for all people.

## 3.1 \*Checking Noise and Vibrations

| No  | Step  |
|-----|---|
| 300 | Listen if there is a scratching or grinding noise in the gear.  |
| 301 | Locate excessive noise by setting a screw driver on the object and use it as an amplifier.  |
| 302 | Touch the gearbox and check if there are excessive vibrations.  |
| 303 | Recommendation, specially in cases of doubt: take a record of the vibration of the gearbox, using the MK4 / MK5 / EVA-625, or VIBRATION PEN (SKF), or "MERLIN" (SKF), or a similar device and make an input in the board-book for later comparison. |
| 304 | If there are excessive noise or vibrations or a significant increase of them, (refer to the records made at an earlier step, if available), proceed as in sections 3.3, 3.4, 3.5, 3.6.  |


## 3.2 Checking General Machine Conditions

| No  | Step  |
|-----|---|
| 305 | Visually inspect the gear for any damage and oil leakage (see Section 4.5).   |
| 306 | Visually check the insulating pads for damage, deformation and general condition.   |
| 307 | Check the coupling rubber (1) as follows (brake must be applied):<br>Try to turn the fly- or hand-wheel. If it can be turned more than about 1.5 mm, the rubber buffers must be replaced. |
| 308 | Check the oil level (2) and add the appropriate oil if necessary.   |

W200, W250 Geared Machines  
Maintenance

K 601887


08



110\_000023\_01


### 3.3 Checking the Thrust Bearing Play

| No  | Step  |
|-----|---|
| 309 | Move the empty car to the top level and pull it up so the counterweight is on the buffer. Switch off the main switch. |
| 310 | Release the brake and keep it in the released position.   |
| 311 | Turn the hand wheel alternating in both directions and check whether the brake drum (1) moves axially.                |
| 312 | If the drum moves (2) axially visible (more than 0.1 mm) re-tighten the thrust bearing according to Section 4.3.      |



### 3.4 \*Checking the Crown Wheel Teeth for Wear

| No  | Step  |
|-----|---|
| 313 | Move the empty car to an upper level.   |
| 314 | Switch off the main switch.   |
| 315 | Take off the plastic cap from the gearbox top.  |
| 316 | Wipe off the oil from the tooth flanks (1) and check visually whether there is a wear step (WS) near to the limit as in table below |
| 317 | If yes, measure the wear step using a feeler gauge (2).   |





**Note**

Compare the measured wear value  $WR = WS1 + WS2$  with those in the table below and take the corresponding actions.

**W200  
(Wear Step  
Limits)**

| W200<br>Gear Ratio   | Max. Permissible Wear Step $WS = WS1 + WS2$ (mm)        |                       |   |                       |
|--|---|-----------------------|---|-----------------------|
|  | Manufacturing Date of Gear Set                          |                       |   |                       |
|  | before end<br>1995                                      | after 1. Jan.<br>1996 | before end<br>1995  | after 1. Jan.<br>1996 |
| 68/1<br>69/2   | 0.5   | 0.7                   | 0.7   | 1.0                   |
| 54/1   | 0.6   | 1.1                   | 0.8   | 1.4                   |
| 55/2   | 0.7   | 1.1                   | 1.0   | 1.5                   |
| 52/3   | 1.0   | 1.6                   | 1.4   | 2.0                   |
| 43/1<br>43/2   | 1.2   | 1.8                   | 1.6   | 2.3                   |
| 41/3   | 1.7   | 2.2                   | 2.2   | 3.0                   |
| <b>Wear Status</b>   | Near end of lifetime                                    |                       | End of lifetime *)  |                       |
| <b>Further actions if values near or equal the limits</b>  | Exchange the gear or install a rope brake within 1 year |                       | Exchange the gear or install a rope brake within 3 months |                       |
| <b>Further actions if values exceed the limits and no rope brake is installed</b>  | Check the gear every 3 months                           |                       | Shut down the installation immediately!                   |                       |
| *) Potential safety risk on further wear.<br>Protection system against uncontrolled movement (e.g. rope brake) reduces the potential safety risk of a breakdown. |   |                       |   |                       |

**W250  
(Wear Step  
Limits)**

| W250<br>Gear Ratio   | Max. Permissible Wear Step WS = WS1 + WS2 (mm)          |                       |   |                       |
|--|---|-----------------------|---|-----------------------|
|  | Manufacturing Date of Gear Set                          |                       |   |                       |
|  | before end<br>1995                                      | after 1. Jan.<br>1996 | before end<br>1995  | after 1. Jan.<br>1996 |
| 68/1<br>69/2   | 0.7   | 1.1                   | 1.0   | 1.5                   |
| 54/1   | 0.8   | 1.3                   | 1.1   | 1.8                   |
| 55/2   | 1.1   | 1.6                   | 1.4   | 2.1                   |
| 52/3   | 1.3   | 1.9                   | 1.8   | 2.5                   |
| 43/1<br>43/2   | 1.7   | 2.2                   | 2.2   | 3.0                   |
| 41/3   | 2.2   | 2.8                   | 2.8   | 3.8                   |
| <b>Wear Status</b>   | Near end of lifetime                                    |                       | End of lifetime *)  |                       |
| <b>Further actions if values near or equal the limits</b>  | Exchange the gear or install a rope brake within 1 year |                       | Exchange the gear or install a rope brake within 3 months |                       |
| <b>Further actions if values exceed the limits and no rope brake is installed</b>  | Check the gear every 3 months                           |                       | Shut down the installation immediately!                   |                       |
| *) Potential safety risk on further wear.<br>Protection system against uncontrolled movement (e.g. rope brake) reduces the potential safety risk of a breakdown. |   |                       |   |                       |

### 3.5 Checking the Crown Wheel for Damage


| No  | Step   |
|-----|--|
| 318 | Move the empty car to the lowest level.  |
| 319 | Switch off the main switch.  |
| 320 | Take off the plastic cap from the gearbox top.   |
| 321 | Wipe off oil from the crown wheel.   |
| 322 | Examine the crown wheel with a flashlight to check if all rivets (3) are vertically positioned and without any damage.                                 |
| 323 | Visually check, if the bronze ring is offset to the hub (4).   |
| 324 | Move the crown wheel stepwise by carefully releasing the brake and visually check the teeth for cracks (1) on both sides with a flashlight and mirror. |



**Note**

People tend to mis-identify scratches as cracks. Cracks (1) look like a very sharp line from the tooth root. Scratches (2) have a certain width like a groove and can start anywhere.

|   |  |                 |           |
|---|--|-----------------|-----------|
| <b>W200, W250 Geared Machines<br/>Maintenance</b> |  | <b>K 601887</b> | <b>08</b> |
|---|--|-----------------|-----------|



**Caution**

In case of cracks or damaged rivets switch off this installation immediately. Open the gearbox and confirm the damage. If damaged rivets or cracks are detected the gear set must be replaced (see K602796). The ropes must be free of load.



**Note**

If the damaged gear is part of a group of installations with identical characteristics open the gearboxes of the remaining installations and check the crown wheels and the worm shafts.

**3.6 Checking the Worm Shaft for Broken Segments**




**Note**

This check can be done either by opening the gearbox or by using the special tool "tooth feeler".

**3.6.1 Check With the "Tooth Feeler"**

| No  | Step  |
|-----|---|
| 325 | Move the empty car to the top level and switch off the main switch.   |
| 326 | Drain the gear oil into a clean tank (W200: 14 litres, W250: 20 litres).  |
| 327 | Insert the tooth feeler (1) into the gear until the mark (2) is at the opening (B).   |
| 328 | Holding the tooth feeler upright (grip horizontal) slide the tip of the feeler (3) between the teeth along the groove edge forth and back (C). Irregularities like rough surface or damages to the tooth can be felt. |
| 329 | Turn the worm shaft 90° and repeat this check on the next groove.   |
| 330 | Repeat this procedure until the entire worm shaft has been checked.   |
| 331 | If there is any irregularity felt there is a potential risk of broken worm shaft segments.  |
| 332 | Seal and mount the drain plug and fill in clean oil.  |



Checking the Worm Shaft



**Caution**

In case of broken worm shaft segments switch off this installation immediately.  
 Open the gearbox and confirm the damage. If broken worm shaft segments are detected the gear set must be replaced (see K602796).  
 If the damaged gear is part of a group of installations with identical characteristics open the gearboxes of the remaining installations and check the crown wheels and the worm shafts.

**3.6.2 Check by Opening the Gearbox**

| No  | Step   |
|-----|--|
| 333 | Move the empty car to the top level and pull it up so the counterweight is on the buffer and the ropes are free of load. |
| 334 | Switch off the main switch.  |
| 335 | Support the traction sheave if it is a flying traction sheave.   |
| 336 | Open the gearbox.  |
| 337 | Examine the complete worm shaft for broken worm shaft segments (use fingertip).  |



**Caution**

In case of broken worm shaft segments switch off this installation immediately.  
 The gear set must be replaced (see K602796).



**Note**

If the damaged gear is part of a group of installations with identical characteristics open the gearboxes of the remaining installations and check the crown wheels and the worm shafts.

**3.7 Exchanging Oil**



**Caution**


Mineral oil is not permitted and must be replaced immediately! Mark the gearbox with the oil plate Mat.No. 126751.  
 Use PAO 320 gear oil only (as to technical norm N 5999120E)



| No  | Step  |
|-----|---|
| 338 | Place a tank (W200: 14 litres, W250: 20 litres) under the drain plug. |
| 339 | Carefully open the drain plug and drain the oil.                      |
| 340 | Seal the drain plug with silicon rubber Mat.No. 999228.               |
| 341 | Insert and tighten the drain plug.                                    |
| 342 | Fill in new oil.  |

### 3.8 Grease outer Bearing

| No  | Step   |
|-----|--|
| 343 | Remove the plastic cover and remove the old, used grease as far as possible. |
| 344 | Apply grease (DIN51825-K3K-20) to the outer bearing.                         |
| 345 | Remount the plastic cover.   |



1 Plastic cover plate

### 3.9 Observation and Measures

#### 3.9.1 Excessive Noise and Vibrations

Excessive noise and vibration may be caused by the system itself or by a defective part of the gearbox.

**Excessive vibration and noise detected already during commissioning**

The problem can have different reasons and is mainly a system problem.

Possible remedial actions:

- Installation of a damper disc when vibration at frequency of tooth engagement
- Use synthetic oil
- Check insulation pads

|   |  |                 |           |
|---|--|-----------------|-----------|
| <b>W200, W250 Geared Machines<br/>Maintenance</b> |  | <b>K 601887</b> | <b>08</b> |
|---|--|-----------------|-----------|

**Excessive or increasing vibration and noise detected after a period of normal operation.**

The problem lies in the gearbox itself. Set a screwdriver on the object and use it as an amplifier.

Carry out the following checks:

- Check thrust bearing and sliding bearing
- Check worm shaft (see Section 3-6) if vibration and rattling noise at the frequency of ~25 - 90 Hz (depending on the gear ratio and power frequency) can be heard
- Check crown wheel

---


### 3.9.2 Pitting

---

Pitting (1) is not dangerous but can lead to wear out or/and vibration. Pitting can proceed progressively, constantly or even disappear as wear increases.

Measures:

- Exchange oil regularly (see recommended interval in Section 3).
- Use correct oil type PAO 320
- Check crown wheel teeth for wear (see Section 3-4)



110\_000002\_01



---

#### Note

---

It is not necessary to replace gear set just due to excessive pitting. If, however, the measurement according to Section 3-4 exceeds the limits, the gear set must be replaced.

---

### 3.9.3 Jerks

---

Jerks during deceleration and final stop in case of 50 % load.

Corrective measure:

- Check gear play (thrust bearing play and crown wheel teeth for wear).
- 

### 3.9.4 Blocked Gear

---

Corrective measures:

- Check worm shaft and bearing
  - Check motor shaft and bearing
- 

### 3.9.5 Development of Gear Set Degradation

---


When a gear set becomes damaged it goes normally through the following phases of degradation:

| Degradation   | Observation   |
|---|---|
| Cracks in the tooth root of the worm shaft or broken worm segments                              | <ul style="list-style-type: none"> <li>• Abnormal noise and vibration (vibration and rattling noise at a frequency of ~25 - 90 Hz, depending on gear ratio)</li> </ul>  |
| Cracks on crown wheel or broken teeth   | <ul style="list-style-type: none"> <li>• Strong noise and vibration (vibration and rattling noise at a frequency of ~25 - 90 Hz, depending on gear ratio)</li> <li>• Jerks, blows per traction sheave turn</li> </ul>   |
| Broken tooth on crown wheel or several broken teeth<br><b>Attention:</b> Very fast degradation! | <ul style="list-style-type: none"> <li>• Enormous noise and vibration (vibration and rattling noise at a frequency of ~25 - 90 Hz, depending on gear ratio)</li> <li>• Blocked gear set</li> <li>• Activation of any of the listed devices:               <ul style="list-style-type: none"> <li>• Detection of over-/underspeed</li> <li>• Speed governor contact</li> <li>• Safety gear contact</li> <li>• Travel time control</li> <li>• Thermal circuit breaker (main switch, motor)</li> </ul> </li> </ul> |

|   |  |                 |           |
|---|--|-----------------|-----------|
| <b>W200, W250 Geared Machines<br/>Maintenance</b> |  | <b>K 601887</b> | <b>08</b> |
|---|--|-----------------|-----------|

## 4 \*Corrective Maintenance

### Special Tools

| Tool  | Picture   | Description   |
|---|---|---|
| Special distance plate 9.5 mm                   | no picture available  | Used when exchanging the hoisting motor<br>Mat.No. 113368 |
| Shims   | no picture available  | Used to adapt exchanged hoisting motor<br>Mat.No. 113369  |
| Erection Tool<br>diam. 61.5 mm<br>diam. 89.5 mm | no picture available  | Used to install the radial lip seal<br>Mat.No. 115183     |
| Hook Wrench                                     |  | Used to tighten the shaft nut<br>Mat.No. 547522           |

Special tools for corrective maintenance


### 4.1 Exchanging the Hoisting Motor

#### 4.1.1 Removing the Hoisting Motor

| No   | Step   |
|------|--|
| 4000 | Move the empty car to the top level and pull it up so the counterweight is on the buffer and the ropes are free of load. Switch off the main switch. |
| 4001 | Take off the fly wheel or hand wheel.  |
| 4002 | Loosen the motor fixing screws and the pins.   |
| 4003 | Take away the hoisting motor completely and loosen the brake arms.   |
| 4004 | Remove the coupling rubbers from the brake drum.   |

#### 4.1.2 Installing the Hoisting Motor


| No   | Step  |
|------|---|
| 4005 | Put the corresponding distance plates (1) onto the machine base.                                  |
| 4006 | Place the new motor on the distance plates. Position the motor with a shaft end distance of 2 mm. |
| 4007 | Attach the fly wheel or hand wheel to the motor.  |




Small Motor (Left) and Large Motor (Right)

### 4.1.3 Motor / Worm Shaft Alignment

| No   | Step   |
|------|--|
| 4008 | Using a ruler (1) measure the radial coupling offset (2) in the four positions: above, below, and at each side (A). If not easily accessible, this check can be performed in three positions spread with a rotation of 120° (B). |




|      |   |
|------|---|
| 4009 | Put shims (3) of suitable thickness under the motor feet to equalize the vertical offset. |
| 4010 | Subsequently fix the special distance plate with 5 mm pins (4).                           |



Small Motor (Left) and Large Motor (Right)

|      |   |
|------|---|
| 4011 | Tighten all motor fastening screws (5).   |
| 4012 | Again check the vertical offset and correct it if necessary.  |
| 4013 | Using a feeler gauge (6) measure the alignment angle (parallel position of both coupling halves) in the four positions: above, below, and at each side. |



110\_000008\_01



### Note

If there is a deviation between the vertical checking points (C), the motor feet at the front against those at the back are at different height. This must be corrected by putting shims of suitable thickness under the motor feet at the hand wheel side.

If there are deviations between the horizontal check points (D), the motor can be shifted sideways at the hand wheel side with a mallet.

**Max. deviation in distance between 4 measuring points: 0.05 mm.**



|      |   |
|------|---|
| 4014 | Pin the motor   |
| 4015 | Remove the pins again and shift the motor backwards   |
| 4016 | Insert new coupling rubbers (with powdered soapstone) |
| 4017 | Shift the motor back and re-install the pins          |
| 4018 | Tighten the motor fixing screws                       |
| 4019 | Re-attach the brake arms                              |
| 4020 | Remove the hand wheel if installed                    |

## 4.2 Replacing the Thrust Bearing

| No   | Step   |
|------|--|
| 4021 | Move the car to the top level and pull it up so the counterweight is on the buffer and the ropes are free of load. Switch off the main switch. |
| 4022 | Lift the ropes off the traction sheave (put them over the outboard bearing).   |
| 4023 | Drain the gear oil (W200: 14 litres, W250: 20 litres).   |



## 4.2.1 Removing the Thrust Bearing

| No   | Step  |
|------|---|
| 4024 | Loosen the hoisting motor, uncouple it and shift it away from the gear. |
| 4025 | Remove the tach/IG on thrust bearing side.                              |




110\_000009\_01

*IG 500 (Left) and AMK (Right)*




110\_000010\_01

*Tacho-generator (Left) and IZ (Right)*



IG 2000



*Thrust Bearing Set*

- 1 Sleeve ring
- 2 Seating for radial lip seal
- 3 Radial lip seal
- 4 O-ring
- 5 Thrust ring
- 6 Shaft nut
- 7 Spacer sleeve
- 8 Thrust bearing
- 9 Spacer ring
- 10 Thrust ring locking screws

**4026** Remove the radial lip seal (3) and the sleeve ring (1).



|             |   |
|-------------|---|
| <b>4027</b> | Remove the shaft nut (6) and the thrust ring (5).                             |
| <b>4028</b> | Remove the thrust bearing (8), the spacer sleeve (7) and the spacer ring (9). |
| <b>4029</b> | Clean the thrust bearing set housing before mounting any new parts.           |

#### 4.2.2 Installing the Thrust Bearing

| No          | Step  |
|-------------|---|
| <b>4030</b> | Lubricate all thrust bearing parts slightly with clean oil.   |
| <b>4031</b> | Clean all seating and the shaft.  |
| <b>4032</b> | Mount bearing case with new O-ring.   |
| <b>4033</b> | Slide the thrust bearing set (8) with spacer ring (9) and spacer sleeve (7) over the shaft.   |
| <b>4034</b> | Block the worm shaft in a way that it can not turn but move in axial direction.   |
| <b>4035</b> | Tighten the shaft nut (6) to press the spacer ring against the shaft shoulder by means of the spacer sleeve (7). Use the hook wrench to tighten the shaft nut (6) with a torque of 150 Nm ... 200 Nm. |
| <b>4036</b> | Tighten the thrust ring (5) by hand until the axial play of the worm shaft is eliminated. The thrust ring must not exert any pressure.  |
| <b>4037</b> | The thrust ring locking screws (10) must be tightened equally one by one in small steps.  |
| <b>4038</b> | Finally tighten the three locking screws with a torque of 10 Nm.  |
| <b>4039</b> | Release the worm shaft and turn the traction sheave at least one turn in both directions and check the axial play (max. 0.005 ... 0.01mm). Readjust the thrust bearing if necessary.                  |
| <b>4040</b> | When re-attaching the tachometer or IG always use new radial lip seal (3) and O-ring (4) (see Section 4-4).   |
| <b>4041</b> | Fill in the oil and check if there is enough oil in the gearbox.  |
| <b>4042</b> | Clean the entire gear housing with solvent.   |
| <b>4043</b> | Put back the hoisting motor in place and fix it according to Section 4-1-2 and mount the ropes.   |

#### 4.3 Re-Tightening the Thrust Bearing



##### Note

Illustrations are given in the Section 4.2.1.

| No          | Step   |
|-------------|--|
| <b>4044</b> | Move the empty car to the top level and pull it up so the counterweight is on the buffer and the ropes are free of load. |
| <b>4045</b> | Remove tachometer or IG.   |

|   |  |                 |           |
|---|--|-----------------|-----------|
| <b>W200, W250 Geared Machines<br/>Maintenance</b> |  | <b>K 601887</b> | <b>08</b> |
|---|--|-----------------|-----------|

| No   | Step   |
|------|--|
| 4046 | Loosen the three thrust ring locking screws.   |
| 4047 | Release the brake and turn the hand wheel or fly wheel in a direction that the worm shaft is moved in axial direction towards the coupling. This to have the play at the outer side of the thrust bearing. |
| 4048 | Tighten the thrust ring (5) by hand until the axial play of the worm shaft is eliminated. The thrust ring must not exert any pressure.   |
| 4049 | The thrust ring (5) locking screws must be tightened equally one by one in small steps.  |
| 4050 | Finally tighten the three locking screws with a torque of 10 Nm.   |
| 4051 | Turn the traction sheave at least one turn in both directions and check the axial play (max. 0.005 mm ... 0.01 mm). Readjust the thrust bearing if necessary.  |
| 4052 | When re-attaching the tachometer or IG always use new radial lip seal (3) and O-ring (4).  |

#### 4.4 Replacing the Radial Lip Seal




##### Note

Illustrations are given in the Section 4.2.1.

##### 4.4.1 Removing the Radial Lip Seal On Coupling Side


| No   | Step   |
|------|--|
| 4053 | Drain the gear oil.  |
| 4054 | Remove the hoisting motor according to Section 4.1.1.  |
| 4055 | Remove the worm bearing at the coupling side.  |
| 4056 | Remove the radial lip seal (1) and the O-ring. Make sure not to damage the seat.   |
| 4057 | Check if the sleeve ring has grooves.<br>The radial lip seal (1) can be positioned either flushing inside (A) or flushing outside (B). If the sleeve ring has grooves on both positions (3) and (4) it must be replaced as well. |



110\_000013\_01

#### 4.4.2 Removing the Radial Lip Seal On Tacho / IG Side

| No   | Step   |
|------|--|
| 4058 | Remove the tacho or IG.  |
| 4059 | Place an oil pan under the worm bearing flange to collect overflowing oil.   |
| 4060 | Remove the radial lip seal (1) and the O-ring.   |
| 4061 | Check if the sleeve ring has grooves.<br>The radial lip seal (1) can be positioned either flushing inside (A) or flushing outside (B). If the sleeve ring has grooves on both positions (3) and (4) it must be replaced as well. |



110\_000014\_01

#### 4.4.3 Installing the Radial Lip Seal On Coupling Side

| No   | Step   |
|------|--|
| 4062 | Clean the shaft and all seating.   |
| 4063 | Slide the sleeve ring over the shaft.  |
| 4064 | Oil the radial lip seal slightly.  |
| 4065 | Using the erection tool with diameter 89.5 mm press the lip seal into its seat.                            |
| 4066 | Oil the worm bearing slightly and insert the O-ring.   |
| 4067 | Slightly lift the worm bearing and carefully slide it over the shaft end.                                  |
| 4068 | Clean the radial lip seal and its surrounding and the bearing flange with solvent to avoid any oil bridge. |
| 4069 | Re-attach the brake and the motor according to Section 4.1.2.  |
| 4070 | Align the motor according to Section 4.1.3.  |

#### 4.4.4 Installing the Radial Lip Seal On Tacho / IG Side

| No   | Step   |
|------|--|
| 4071 | Clean the shaft and all seating.   |
| 4072 | Slide the sleeve ring over the shaft.  |
| 4073 | Oil the radial lip seal slightly.  |
| 4074 | Using the erection tool with diameter 61.5 mm press the lip seal into its seat.                            |
| 4075 | Oil the worm bearing slightly and insert the O-ring.   |
| 4076 | Slightly lift the worm bearing and carefully slide it over the shaft end.                                  |
| 4077 | Clean the radial lip seal and its surrounding and the bearing flange with solvent to avoid any oil bridge. |
| 4078 | Check the axial play of the worm shaft according to Section 3-3.   |
| 4079 | If necessary re-tighten the thrust bearing according to Section 4-3.                                       |
| 4080 | Re-attach the tacho/IG.  |

#### 4.5 Repair Oil Leakage




| No   | Step   |
|------|--|
| 4081 | Clean the entire machine with a solvent and trace the leak.  |
| 4082 | If it appears that the oil leak at the radial lip seal, clean properly the rubber collar and the shaft with solvent. |
| 4083 | If leak does not stop replace the radial lip seal according to Section 4.4.  |

## 4.6 Exchanging the Bearing Bushings on Main Shaft



### Note

Prior to dismantling the bushes, the following components must be demounted from the main shaft:

| Traction sheave position                         |  | Components                                  |
|--|--|---|
| Traction sheave flying, without outboard bearing |    | Traction sheave                             |
| Traction sheave inboard, with outboard bearing   |   | Outboard bearing and traction sheave        |
| Traction sheave flying, with outboard bearing    |  | Crown wheel (pressing force approx. 220 kN) |



### Note

When demounting the outboard bearing, keep it always in vertical position. If the outboard bearing is "swinging", the packing rings might be damaged. It is recommended to fix the outboard bearing on the traction sheave, so that it always stays square to the main shaft.



| No   | Step  |
|------|---|
| 4084 | Move the car to the top level and pull it up so the counterweight is on the buffer and the ropes are free of load.                                |
| 4085 | Lift the ropes off the traction sheave.   |
| 4086 | Drain the gear oil (W200: 14 litres, W250: 20 litres).  |
| 4087 | Demount the upper casing of the gear. Lift the main shaft with the worm wheel out of the casing. Remove old o-rings (2) and bearing bushings (1). |
| 4088 | Clean main shaft (4) and bearing seats with solvent.  |
| 4089 | Remove previous silicon from the upper and lower fitting surfaces.  |

W200, W250 Geared Machines  
Maintenance

K 601887

08

| No   | Step  |
|------|---|
| 4090 | Put new bearing bushings (1) into the bearing seats in such a way that the position fixing hole is right above the position fixing pin (3). |



110 000018 01


|      |  |
|------|--|
| 4091 | Mark the casing edge on the bearing bush (1).  |
| 4092 | Lubricate the bearing bushings (1) slightly and push them on the shaft (4) with a distance of approx. 10.mm away from the crown wheel. |
| 4093 | Lower the main shaft very carefully to insert the crown wheel into the worm shaft.   |



#### Caution

Make sure that the main shaft does not become tilted while putting it in, as then the crown wheel might get jammed.

|      |  |
|------|--|
| 4094 | After inserting the crown wheel into the worm shaft, lift the main shaft about 3 mm and position the bearing bushings.               |
| 4095 | Using the markings previously made, move the bearing bushings to their final position.   |
| 4096 | Lower the main shaft back into the bearing seats.  |
| 4097 | Fit the O-rings and shift them into the final position.  |
| 4098 | Carefully coat both fitting surfaces with silicon rubber seal Mat.No. 999228   |
| 4099 | Make sure to apply rubber seal (7) close to the tapped hole (5), so that the oil groove in the upper casing does not become blocked. |
| 4100 | Remount the upper casing (9).  |
| 4101 | Carefully seal the parting gap (6) with silicon rubber Mat.No. 999228.   |



Gear overview

|             |   |
|-------------|---|
| <b>4102</b> | Tighten the bolts (10) with a torque of 150 Nm ... 200 Nm.  |
| <b>4103</b> | Clean the drain plug and seal it with silicon rubber Mat.No. 999228. Insert and tighten the drain plug. |
| <b>4104</b> | Fill in new oil (W200: 14l, W250 20l).  |



**Caution**

Use PAO 320 gear oil only (as to technical norm N 5999120E).

**4.7 \*Replacement of Gear Set**

Replacement according to [K 602796](#)

**4.8 \*Setting and Repairing of Mechanical Brake**

Setting and repairing according to [K 601888](#)


|   |  |                 |           |
|---|--|-----------------|-----------|
| <b>W200, W250 Geared Machines<br/>Maintenance</b> |  | <b>K 601887</b> | <b>08</b> |
|---|--|-----------------|-----------|

## 5 \*Installing the Traction Sheave Damper

Before ordering or installing a traction sheave damper examine the gearbox thoroughly.

- Check noise, vibrations, jerks, pitting etc. as described in section 3.9
- Check worm shaft for broken segments as described in section 3.6
- Check worm wheel for damage as described in section 3.5

### 5.1 Delivery Content



| Pos | Item   | Material No.       |                    |
|-----|--|--------------------|--------------------|
|     |  | W200<br>(L271 006) | W250<br>(L271 023) |
| 1   | Damper disk                                  | 127 008            | 127 025            |
| 2   | Additional disk (for 2-start worm gear only) | 127 045            | --                 |
| 14  | Bag for 2-start worm gear                    | 127 047            | 127 026            |
| 14  | Bag for 3-start worm gear                    | 127 009            |                    |
|     | Bag contains:                                |                    |                    |
| 3   | 1 torsion spring                             |                    |                    |
| 4   | 1 clamp nut                                  |                    |                    |
| 5   | 1 cover cap                                  |                    |                    |
| 6   | 1 thread bolt M20-8.8                        |                    |                    |
| 7   | 1 washer                                     |                    |                    |

**W200, W250 Geared Machines  
Maintenance**

**K 601887**

**08**



| Pos | Item  | Material No.       |                    |
|-----|---|--------------------|--------------------|
|     |   | W200<br>(L271 006) | W250<br>(L271 023) |
| 8   | 1 hex nut M20 for fitting procedures                      |                    |                    |
| 8   | 1 hex nut M20 for tightening the thread bolt (6)          |                    |                    |
| 9   | 3 hex soc screw M12                                       |                    |                    |
| 10  | 1 protective plug for nut M20                             |                    |                    |
| 11  | 1 small bottle of LOCTITE 243, 10ml (not shown)           |                    |                    |
| 12  | 3 Fl. Soc. screw M8, (only 2-start worm gear) (not shown) |                    |                    |

| Gear Ratio           | Frequency | Gear type     | A (mm) |      |
|----------------------|-----------|---------------|--------|------|
|                      |           |               | W200   | W250 |
| 41:3<br>52:3         | 50Hz      | outer bearing | 42     | 45   |
|                      |           | overhung      | 38     | 42   |
|                      | 60Hz      | outer bearing | 53     | 59   |
|                      |           | overhung      | 50     | 56   |
| 43:2<br>55:2<br>69:2 | 50Hz      | outer bearing | 39     | 23   |
|                      |           | overhung      | 36     | 20   |
|                      | 60Hz      | outer bearing | 50     | 34   |
|                      |           | overhung      | 47     | 31   |

## 5.2 Special Tools

### Special Tools

| Tool                            | Description                                  |
|---------------------------------|--|
| Torque wrench 80Nm<br>... 300Nm |  |
| Socket SW30                     |  |
| 1 long socket wrench<br>SW 10   | Used for hex soc screw M8 (12)               |
| 2 Wrench SW30                   |  |
| Cleaning brush                  | To wash out the bore center at the shaft end |
| Calliper gauge                  |  |

*Special tools for traction sheave damper installation*

**W200, W250 Geared Machines  
Maintenance**

**K 601887**

**08**

### 5.3 Preparatory Work



#### Danger

To prevent any traction sheave movement turn off the main switch.

| No  | Step   |
|-----|--|
| 500 | Remove grease and dirt from the shaft end face and from the center bore of the shaft end.                                    |
| 501 | Remove grease and dirt from the center of damper disk (1), from the threaded bolt (6) and torsion spring (3) and clean them. |

### 5.4 Installation of the Traction Sheave Damper



#### Note

Detailed information and Illustrations are given in the Section 5.1.

| No  | Step  |
|-----|---|
| 502 | Screw in the two hex nuts (8) onto the threaded bolt (6) and lock them against each other with two wrenches SW30.   |
| 503 | Coat one end of the threaded bolt (6) on a length of approx. 30 mm with LOCTITE 243 and screw the threaded bolt immediately into the center bore of the shaft end and tighten it. |
| 504 | Remove the two hex nuts (8) from the threaded bolt (6).   |
| 505 | Screw torsion spring (3) into damper disk (1).  |
| 506 | Adjust measurement A as per table above.  |
| 507 | Screw clamp nut (4) onto torsion spring (3) with a gap of approximately 3mm and tighten stepwise the 3 hex soc screws (9) and finally tighten them with a torque of 80 Nm.        |
| 508 | Lift the assembled damper disk (1) and slide it onto the threaded bolt (6).   |
| 509 | Slide washer (7) onto the threaded bolt (6).  |
| 510 | Coat the outer end of the threaded bolt (6) with LOCTITE 243 and screw on hexagonal nut (8) onto the threaded bolt immediately and tighten the nut with a torque of 300 Nm.       |
| 511 | Attach the protective plug (10).  |
| 512 | W200 with 2-start worm gear: Attach the disk (2) using the 3 Fl. soc. screws M8 (13) to the damper disk (1).  |
| 513 | To ensure quiet running tighten evenly the 3 hex soc screws (9) with a torque of 80 Nm.   |

## 5.5 Final Work

| No  | Step  |
|-----|---|
| 514 | Switch on the main switch.  |
| 515 | Make subjective assessment of ride quality.   |
| 516 | In case of non-satisfactory ride quality, make a new assessment of the ride quality during an upward travel with empty car.   |
| 517 | Make another trip downward with empty car and make a new judgment of the ride quality by comparing it with the upward travel. |
| 518 | Switch off the main switch.   |
| 519 | Mark actual damper disk position against a reference point, (e.g. machine frame) and loosen the screws (9).                   |
| 520 | If the ride quality is worse (louder) during the upward travel, turn the damper disk clock wise, in steps of 180°.            |
| 521 | If the ride quality is worse during the downward travel, turn the damper disk counter clock wise, in steps of 180°.           |
| 522 | To ensure quiet running tighten evenly the 3 hex soc screws (9) with a torque of 80 Nm.                                       |



### Caution

Always tighten the 3 hex soc as described before moving the car in any direction.

|     |   |
|-----|---|
| 523 | Switch on the main switch.                                |
| 524 | Again make subjective assessment of ride quality.         |
| 525 | Repeat adjustment until the ride quality is satisfactory. |



### Note

When the ride quality can not be satisfactorily adjusted, fill in form J 271021 completely.

|     |  |
|-----|--|
| 526 | Mount cover cap (5).   |
| 527 | Measure A= _____ mm.   |
| 528 | Store this instruction with inserted measure A per elevator in the machine room. |



### Caution

After an engagement of the safety gear or an impact on the buffers of the car or counterweight with VKN the hex nut (8) and the hex soc screws (9) have to be checked.

|   |  |          |    |
|---|--|----------|----|
| W200, W250 Geared Machines<br>Maintenance |  | K 601887 | 08 |
|---|--|----------|----|

## 5.6 Reporting

---

When Section 5.5 is satisfactorily completed, fill in form J 271021 up to Point 4.  
Return the completed reporting instruction form J 271021 to the address given in the form.

---

|   |  |                 |           |
|---|--|-----------------|-----------|
| <b>W200, W250 Geared Machines<br/>Maintenance</b> |  | <b>K 601887</b> | <b>08</b> |
|---|--|-----------------|-----------|