National Association of Lift Makers



33/34 Devonshire Street

London W1N 1RF

Director D M Fazakerley

telephone:

071-935 3013

fax:

071-935 3321

To: All Members

cc: The Quality and Technical Committee (Code No 1454)

29 November 1991

Dear Sir,

Hammond & Champness Type DC 68 Landing Door Interlock Equipment

To avoid abuse and render secure the above mentioned type of landing door lock the Company recommends a lock beak setting procedure as illustrated in the enclosed drawings. It is stated:

'Once the beak movement has been adjusted, the position is set. Inspection should not be necessary over and above normal service requirements, it is recommended that this type of lock is inspected at six monthly intervals'.

Will members please be guided accordingly.

Yours faithfully,

D M Fazakerley

Director

DC 68 LANDING INTERLOCK EQUIPMENT






FIG.1





FIG 2





LOCK BEAK

LOCK BOX

9m.m. penetration

Linkage arm location LOCK

LOCK BEAK SETTING WITH PICK-UP ROLLER RESTING

LOCK BEAK IN LOCKED POSITION

ON ITS STOP see fig 2

Pick-up roller resting on its stop see fig 2

Fig 3

notel

ensure that the lock box cover fixing screw does not prevent full beak penetration

Fig 4